


## 延長センサケーブル

## 延長センサケーブル


●外形図 Outline drawing

(1) 3P-S-0102 / 3P-RBT-0102 / 4P-S-0102 / 4P-RBT-0102 / 3S-RBT-0102


単位:mm (Units:mm)




(2) 3P-RBT-0103 / 3S-RBT-0103 / 4P-RBT-0103



(3) 3S-RBT-8002 / 4P-S-8002 / 4P-RBT-8002




(4) 3S-RBT-8003 / 4P-RBT-8003




(5) 4S-RBT-4344


単位:mm (Units:mm)



(6) 5S-RBT-4344



(7) 3S-RBT-0144 / 4P-RBT-0144



- 01
- 02
- 03
- 04
- 05
- 06
- 07
- 08
- 09
- 10
- 11
- 12
- 13
- 14